

CLEAN AND DISINFECT IN 4 EASY STEPS

BEST PRACTICES

EYEWEAR



It is recommended to follow your state and local requirements for tanning eyewear. In times in increased caution it is important to offer disposable eyewear for each customer or the inexpensive purchase of individual eyewear pods that do no pass from member to member.

FACILITY





For best practice, properly sanitize all equipment, door handles, countertops, and anything that is frequently touched by your customers.

01

SPRAY & WAIT

After each session, spray the tanning bed spray with Lucasol™ disinfectant and let disinfectant sit for 60 seconds.

SANITIZE

02

WIPE DOWN

Wipe tanning bed surfaces to remove Lucasol™ and any tanning lotion residue. The bed is now sanitized.



03

SPRAY & WAIT

For deep cleaning at the end of the day, spray tanning equipment and let Lucasol sit for 10 minutes to achieve 100% disinfection, killing 100% of bacteria, fungus, and virus.

DISINFECT

04

WIPE DOWN

Wipe remaining Lucasol™ from the surface of the bed. The bed is now disinfected.



THINGS TO REMEMBER

- 1. Do not rub the acrylics with a dry cloth and remove jewelry like rings, watches and bracelets during cleanings of the equipment. You risk damaging and scratching.
- 2. Clean the outside panels of the tanning beds. Did you know that if this is not disinfected, over time, the places that have been touched can become stained from the heat and light? Remove fingerprints and other marks carefully.
- 3. Lamps and filters can be cleaned with a damp cloth without cleaning agents when necessary. We recommend deep cleaning the inside (under the acrylic) of the bed during each lamp change.

For more information: 877.244.6183

LUCASOL™ One Step™

When mixed to 700 ppm*, double quart, LUCASOL ONE STEP has the highest available germ-killing power in the industry. Our hospital-grade formula helps stop the spread of contagious diseases. Dye and perfume free; minimizes any possible allergic reaction to customers and employees. * Disinfect Dilution: 2 ounces per gallon of water

Lucasol kills the following pathogens:

- Avian influenza A (H5 N1)
- Hepatitus B
- Hepatitus C
- Herpes Simplex Type 1
- HIV 1
- Methicillin Resistant Staphylococcus aureus (MRSA)
- Staphylococcus aureus
- Pseudomonas aeruginosa
- Salmonella cholerasuis
- Canine Parvovius
- Escherichia coli (e.coli)
- Feline Picornavirus
- Human Coronavirus
- Klebsiella pneumoniae
- Listeria Monocytogenes
- SARS Associat4ed Cornonavirus
- Streptococcus Faecalis
- Streptococcus pyogenes
- Vaccinia Pox

- Vancomycin Intermediate resistant Staphylococcus aureus
- Adenovirus type 2
- Bovine Viral Diarrhea Virus
- Brevibacterium ammoniagenes
- Canine Adenovirus
- Canine Coronavirus
- Canine Parainfluenza Virus
- Enterobacter aerogenes
- Feline Calicivirus
- Feline Coronavirus
- Feline Panleukopenia
- Feline Rhinotracheitis
- Influenza A2/Japan
- -Norovirus
- -Odor causing bacteria
- -Porcine Parvovirus
- -Salmonella schottmuelleri
- -Shigella dysenteriae
- -Streptococcus salivarius
- -Swine Influenza A (H1N1)