



## I. DISINFECT



Did you leave units on? – Using the internal breaker, power down each unit, and fully disinfect. Once unit has been disinfected and all components are dry, power back on, one unit at a time, allowing 15 second intervals between.

Did you turn units off? – Disinfect all equipment. Once unit has been disinfected and all components are dry, power back on, one unit at a time, allowing 15 second intervals between.

Note: It is very important to follow these steps as instructed, turning too many units on at once can cause a power fluctuation (black out/brown out/voltage spike) which could result in damage to the tanning bed.

## 2. PREVENTATIVE MAINTENANCE

Click on the equipment name to preview the preventative maintenance steps for each equipment in the user manual.

### LAYDOWN EQUIPMENT

- o [PF 42/4 HLT](#)
- o [PF 48/4](#)
- o [PF 42/4](#)
- o [AFFINITY 700](#)
- o [AFFINITY 500](#)
- o [PASSION 40/3](#)
- o [PASSION 40/3+](#)

### STAND UP EQUIPMENT

- o [PF 7200 HLT](#)
- o [SUNRISE 6200](#)
- o [SUNRISE 480](#)
- o [BEAUTY ANGEL 7200](#)
- o [BEAUTY ANGEL RVT30](#)

Note: This information can be found in the Cleaning and Maintenance section of the equipment user manual. Visit [ergolineplanetfitness.com](http://ergolineplanetfitness.com)



## 3. TEST CYCLE - TANNING SESSIONS

After equipment has been disinfected and powered back on, it is important to run test sessions to ensure all components are working properly. (Beds, Lamps).

The equipment and lamps can have the tendency of “slow” starting after sitting for an extended period with no usage. It is recommended to run a minimum of 2-3 full sessions to allow the equipment and lamps to fully acclimate.

1. Run 3 test sessions for each piece of equipment.
2. If you have in house technicians and/or an asset management ticketing system, please follow standard process and procedures for reporting issues. If additional information is required, please contact JK Service 877.244.6183 or JK Lamps 800.793.6760



4. Disinfect all equipment a 2nd time once all beds are operating properly.
5. Remove all eyewear and replace with disposable or individual.
6. Clean tanning rooms thoroughly, sanitize floors, clean door handles, and any surface that is routinely touched during a session.

These are our standard cleaning guidelines to get equipment ready for reopening. This does not address the required disinfecting that will be in place once open. Further guidance on disinfecting to follow in later communication.